

P-3800

Reset Volume Controller



Description

The P-3800 Reset Volume Controller regulates the flow of air in Variable Air Volume (VAV) boxes. The P-3800 controls the output volume, between adjustable minimum and maximum limits, in response to a reset signal from a thermostat or some other master controller. The P-3800 is available in two models.

Features

- · fully adjustable
 - reset start point
 - reset range
 - minimum and maximum flow set points

- provides controllable flow down to 0.01 in.
 WG velocity pressure
- reset range adjustable 0.15 to 1.6 in. WG
- isolated diaphragm design accepts any sensing line
- · fits most competitors' mounting brackets
- provided with barbed fittings on all ports
- includes a replaceable filter/orifice assembly
- · constant reset span

To Order

Specify the code number from the following selection chart.

Repair Parts

Code Number	Description
P-3800-600	Replacement Filter/Orifice Assembly

Selection Chart

Code	Description		
Number	Thermostat	Configuration	
P-3800-1	Direct Acting	DADR	
	Reverse Acting	RARR	
P-3800-2	Reverse Acting	DARR	
	Direct Acting	RADR	

Accessories

Code Number	Description
A-4000-1037	Inline Air Supply Filter (Recommended for Heavily Contaminated Air Supply Systems)
F-300 Series	Straight Couplers
F-1000 Series	Sealing Caps