## Pushbutton Units and Indicator Lights SIRIUS Plastic 3SB3, O Round Design, 22 mm

## **Pushbuttons**

## Selection and ordering data

	Version	Color of operator	Inscription	Order No.	List Price \$ 1 unit	Weight approx. kg	Pack Unit
	<i>including holder</i> <sup>1</sup> )						
Pushbutton with flat button	Pushbutton with flat button	black red yellow green blue white grey clear <sup>2</sup> ) black black black black black black black black black black	down up forward reverse on start reset	3SB3000-0AA11 3SB3000-0AA21 3SB3000-0AA31 3SB3000-0AA51 3SB3000-0AA51 3SB3000-0AA51 3SB3000-0AA51 3SB3000-0AA11-ZEE 3SB3000-0AA11-ZEF 3SB3000-0AA11-ZEB 3SB3000-0AA41-ZEB 3SB3000-0AA41-ZEL 3SB3000-0AA41-ZEL	5.80 5.80 5.80 5.80 5.80 5.80 5.80 8.10 8.10 8.10 8.10 8.10 8.10 8.10 8	0.02	1
Pushbutton with raised button	Pushbutton with raised button	black red yellow blue white red red	off stop	3SB3000-0BA11 3SB3000-0BA21 3SB3000-0BA31 3SB3000-0BA51 3SB3000-0BA61 3SB3000-0BA21-ZEC 3SB3000-0BA21-ZEK	5.80 5.80 5.80 5.80 5.80 8.10 8.10	0.02	1
	Pushbutton, locking with raised button, can be locked by depress- ing and turning clockwise; unlocking by turning anti- clockwise	black red		3SB3000-0CA11 3SB3000-0CA21	23.00 23.00	0.03	1
	Pushbutton with raised front ring (Height 13 mm)	black red yellow green blue white		3SB3000-0AA12 3SB3000-0AA22 3SB3000-0AA32 3SB3000-0AA42 3SB3000-0AA52 3SB3000-0AA62	12.80 12.80 12.80 12.80 12.80 12.80 12.80	0.02	1
ushbutton with raised front ng	Pushbutton with raised front ring with castellations, (Height 13 mm)	black red yellow green		3SB3000-0AA13 3SB3000-0AA23 3SB3000-0AA33 3SB3000-0AA43	25.50 25.50 25.50 25.50	0.02	1
ushbutton with raised front	Illuminated pushbutton with flat button incl. holder for 3 elements	red <sup>2)</sup> yell. <sup>2)</sup> green <sup>2)</sup> blue <sup>2)</sup> white clear <sup>2)</sup>		3SB3001-0AA21 3SB3001-0AA31 3SB3001-0AA41 3SB3001-0AA51 3SB3001-0AA61 3SB3001-0AA71	9.50 9.50 9.50 9.50 9.50 9.50 9.50	0.02	1
ng (castell.)	Illuminated pushbutton with raised button incl. holder for 3 elements	red yellow green blue clear		3SB3001-0BA21 3SB3001-0BA31 3SB3001-0BA41 3SB3001-0BA51 3SB3001-0BA71	9.50 9.50 9.50 9.50 9.50 9.50	0.02	1
	Pushbutton, with flat button maintained, unlatching by pressing	black red yellow green blue white grey		3SB3000-0DA11 3SB3000-0DA21 3SB3000-0DA31 3SB3000-0DA41 3SB3000-0DA51 3SB3000-0DA61 3SB3000-0DB51	9.00 9.00 9.00 9.00 9.00 9.00 9.00	0.07	1
Ô	Illuminated pushbutton, with flat button incl. holder for 3 elements, maintained, unlatching by pressing	$\begin{array}{c} \operatorname{red}^{(2)} \\ \operatorname{yell}^{(2)} \\ \operatorname{green}^{(2)} \\ \operatorname{blue}^{(2)} \\ \operatorname{white}^{(2)} \\ \operatorname{clear}^{(2)} \end{array}$		3SB3001-0DA21 3SB3001-0DA31 3SB3001-0DA41 3SB3001-0DA51 3SB3001-0DA61 3SB3001-0DA71	14.10 14.10 14.10 14.10 14.10 14.10 14.10	0.07	1

Illuminated pushbuttor with raised button

For contact blocks and lamp holders, see pages 10/62-10/65. For insert labels and back plates, see pages 10/66-10/69. For other accessories, see pages 10/70-10/74.

1) Also available without holder. Supplement Order No. with "-Z" and quote order code "B01".

2) Inscription by inserting a label is possible.

## Selection and ordering data



Mushroom pushbutton, Ø 30 mm



Mushroom pushbutton, Ø 40 mm



Illuminated mushroom pushbutton, Ø 30 mm



Illuminated mushroom pushbutton, Ø 40 mm

Push-pull button, Ø 30 mm



Push-pull button, Ø 40 mm

Version	Color of operator	Order No.	List Price \$ 1 unit	Weight approx. kg	Pack Unit
including holder <sup>1</sup> )					
Mushroom pushbutton, Ø 30 mm	black red yellow green	3SB3000-1DA11 3SB3000-1DA21 3SB3000-1DA31 3SB3000-1DA41	14.10 14.10 14.10 14.10	0.03	1
Mushroom pushbutton, Ø 40 mm	black red yellow green	3SB3000-1GA11 3SB3000-1GA21 3SB3000-1GA31 3SB3000-1GA41	14.10 14.10 14.10 14.10	0.03	1
Illuminated mushroom pushbutton, Ø 30 mm incl. holder for 3 elements	yellow green white	3SB3001-1DA31 3SB3001-1DA41 3SB3001-1DA61	19.90 19.90 19.90	0.03	1
Illuminated mushroom pushbutton, Ø 40 mm incl. holder for 3 elements	yellow green white	3SB3001-1GA31 3SB3001-1GA41 3SB3001-1GA61	19.90 19.90 19.90	0.03	1
Push-pull button Ø 30 mm maintained, unlatching by pulling	black red <sup>2)</sup>	3SB3000-1EA11 3SB3000-1EA21	21.00 21.00	0.03	1
Push-pull button Ø 40 mm maintained, unlatching by pulling	black red	3SB3000-1CA11 3SB3000-1CA21	21.00 21.00	0.03	1
Push-pull button, Ø 30 mm, illuminated maintained, incl. holder for 3 elements, unlatching by pulling	red yellow green blue clear	3SB3001-1EA21 3SB3001-1EA31 3SB3001-1EA41 3SB3001-1EA51 3SB3001-1EA71	24.50 24.50 24.50 24.50 24.50	0.03	1
Push-pull button, Ø 40 mm illuminated maintained, incl. holder for 3 elements, unlatching by pulling	red yellow green blue clear	3SB3001-1CA21 3SB3001-1CA31 3SB3001-1CA41 3SB3001-1CA51 3SB3001-1CA71	24.50 24.50 24.50 24.50 24.50 24.50	0.03	1

For contact blocks and lamp holders, see pages 10/62-10/65. For insert labels and back plates, see pages 10/66-10/69.

For other accessories, see pages 10/70-10/74.

1) Also available without holder. Supplement Order No. with "-Z" and quote order code "B01".

2) Maximum components provided: 3 single pole or 2 double-pole contact elements. When using the 3SB39 01–0AB holder, the central command position must not be empty.

**Pushbuttons** 

10/41