

Valve Spring Kits Sorted by Valve Code Number

Valve Body	Valve Size (in.)	Spring Range (psig)	Actuator	Spring Kit
V-3011	1 and 1-1/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6024
V-3011	1 and 1-1/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021
V-3011	1-1/2 - 2	3 - 6	V-3000-1 or V-3000-2	V-3754-6010
V-3011	1-1/2 - 2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3011	1/2 and 3/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
V-3011	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-3020	1 and 1-1/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6024
V-3020	1 and 1-1/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021
V-3020	1-1/2 - 2	3 - 6	V-3000-1 or V-3000-2	V-3754-6010
V-3020	1-1/2 - 2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3020	1/2 and 3/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
V-3020	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-3100	1/2 and 3/4	3 - 6	V-3802 or V-4000	V-3800-6002
V-3100	1/2 and 3/4	9 - 13	V-3802 or V-4000	V-3800-6003
V-3212	1 and 1-1/4	4 - 8	V-3000-1 or V-3000-2	V-4322-6001
V-3212	1 and 1-1/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021
V-3212	1-1/2 - 2	4 - 8	V-3000-1 or V-3000-2	V-3974-6008
V-3212	1-1/2 - 2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3212	1/2 and 3/4	4 - 8	V-3000-1 or V-3000-2	V-4332-6001
V-3212	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-3752	1 and 1-1/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6024
V-3752	1 and 1-1/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021
V-3752	1-1/2 - 2	3 - 6	V-3000-1 or V-3000-2	V-3754-6010
V-3752	1-1/2 - 2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3752	1/2 and 3/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
V-3752	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-3754	1 and 1-1/2	3 - 6	V-3000-1 or V-3000-2	V-3754-6011
V-3754	1 and 1-1/2	9 - 13	V-3000-1 or V-3000-2	V-3754-6008
V-3754	1/2 and 3/4	3 - 6	V-3000-1 or V-3000-2	V-3754-6010
V-3754	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3755	1 and 1-1/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6024
V-3755	1 and 1-1/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021
V-3755	1-1/2 - 2	3 - 6	V-3000-1 or V-3000-2	V-3754-6010
V-3755	1-1/2 - 2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3755	1/2 and 3/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
V-3755	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-3766	1/2	3 - 6	V-3000-1 or V-3000-2	V-3754-6010
V-3800	1/2 and 3/4	3 - 6	V-3802 or V-4000	V-3800-6002
V-3800	1/2 and 3/4	9 - 13	V-3802 or V-4000	V-3800-6003
V-3854	1/2	3 - 6	V-3802 or V-4000	V-3754-6012
V-3854	1/2	9 - 13	V-3802 or V-4000	V-3754-6013
V-3964	1/2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3966	1/2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3970	1 and 1-1/4	4 - 8	V-3000-1 or V-3000-2	V-4322-6001
V-3970	1 and 1-1/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021
V-3970	1-1/2 - 2	4 - 8	V-3000-1 or V-3000-2	V-3974-6008
V-3970	1-1/2 - 2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-3970	1/2 and 3/4	4 - 8	V-3000-1 or V-3000-2	V-4332-6001
V-3970	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6022

Valve Spring Kits Sorted by Valve Code Number (Continued)

Valve Body	Valve Size (in.)	Spring Range (psig)	Actuator	Spring Kit
V-3974	1 and 1-1/2	4 - 8	V-3000-1 or V-3000-2	V-3974-6009
V-3974	1 and 1-1/2	9 - 13	V-3000-1 or V-3000-2	V-3754-6008
V-3974	1/2 and 3/4	4 - 8	V-3000-1 or V-3000-2	V-3974-6008
V-3974	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-4322	1 and 1-1/4	4 - 8	V-300-1 or V-3000-2	V-4322-6001
V-4322	1 and 1-1/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021
V-4322	1-1/2 - 2	4 - 8	V-3000-1 or V-3000-2	V-3974-6008
V-4322	1-1/2 - 2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-4322	1/2 and 3/4	4 - 8	V-3000-1 or V-3000-2	V-4332-6001
V-4322	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-4324	1 and 1-1/2	4 - 8	V-3000-1 or V-3000-2	V-3974-6009
V-4324	1 and 1-1/2	9 - 13	V-3000-1 or V-3000-2	V-3754-6008
V-4324	1/2 and 3/4	4 - 8	V-3000-1 or V-3000-2	V-3974-6008
V-4324	1/2 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-4332	1/2	4 - 8	V-3000-1 or V-3000-2	V-4332-6001
V-4332	1/2	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-4333	1/2	4 - 8	V-3000-1 or V-3000-2	V-4332-6001
V-4333	1/2	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-4334	1/2	4 - 8	V-3000-1 or V-3000-2	V-4332-6001
V-4334	1/2	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-4440	1/2	4 - 12	V-3000-1 or V-3000-2	V-4440-6002
V-4440	5/8	4 - 12	V-3000-1 or V-3000-2	V-4440-6002
V-4440	1/2 and 5/8	6 - 9	V-3000-1 or V-3000-2	V-4440-6001
V-4510	1 and 1-1/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6024
V-4510	1-1/2 - 2	3 - 6	V-3000-1 or V-3000-2	V-3754-6010
V-4510	1/2 and 3/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
V-5216	1/2	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
V-5216	3/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6024
V-5230	1	3 - 7	V-3000-1 or V-3000-2	V-5230-6002
V-5230	1/2 and 3/4	3 - 7	V-3000-1 or V-3000-2	V-5230-6001
V-5250	1 and 1-1/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6024
V-5250	1-1/2 - 2	3 - 6	V-3000-1 or V-3000-2	V-3754-6010
V-5250	1/2 and 3/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
V-5416	1/2	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-5416	3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021
V-5430	1/2 and 3/4	9 - 14	V-3000-1 or V-3000-2	V-5430-6001
V-6139	1/2	9 - 13	V-3000-1 or V-3000-2	V-3754-6009
V-6143	3/8 and 3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-7216	1/2	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
V-7216	3/4	3 - 6	V-3000-1 or V-3000-2	V-3752-6024
V-7416	1/2	9 - 13	V-3000-1 or V-3000-2	V-3752-6022
V-7416	3/4	9 - 13	V-3000-1 or V-3000-2	V-3752-6021

Valve Spring Kits Sorted by Valve Code Number (Continued)

Valve Body	Valve Size (in.)	Spring Range (psig)	Actuator	Spring Kit
VG7000	1/2 or 3/4	3 - 6	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1001
VG7000	1/2 or 3/4	3 - 6	V-3801-8001	VG7000-1010
VG7000	1/2 or 3/4	4 - 8	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1002
VG7000	1/2 or 3/4	4 - 8	V-3801-8001	VG7000-1011
VG7000	1/2 or 3/4	9 - 13	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1003
VG7000	1/2 or 3/4	9 - 13	V-3801-8001	VG7000-1012
VG7000	1/2 or 3/4	Spring Kit with Three Springs: 3 - 6, 4 - 8, 9 - 13 (Includes hardware to adapt one valve only)	V-3801-8001	VG7000-1015
VG7000	1/2 or 3/4	Not Applicable	V-400	VG7000-1013
VG7000	1 or 1-1/4	3 - 6	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1004
VG7000	1 or 1-1/4	4 - 8	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1005
VG7000	1 or 1-1/4	9 - 13	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1006
VG7000	1-1/2 or 2	3 - 6	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1007
VG7000	1-1/2 or 2	4 - 8	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1008
VG7000	1-1/2 or 2	9 - 13	V-3000-8001, V-3000-8003, or V-3000-8011	VG7000-1009
VG7000	1, 1-1/4, 1-1/2 or 2	Not Applicable	V-400	VG7000-1014
VT Series	1/2	3 - 6	V-3802 or V-4000	V-9999-6001
VT Series	1/2	4 - 8	V-3802 or V-4000	V-9999-6002
VT Series	1/2	9 - 13	V-3802 or V-4000	V-9999-6003
VT Series (all)	1/2	3 - 6	V-3000-1 or V-3000-2	V-3752-6023
VT Series (all)	1/2	4 - 8	V-3000-1 or V-3000-2	V-4332-6001
VT Series (all)	1/2	9 - 13	V-3000-1 or V-3000-2	V-3752-6022