Burner Control/Flame Safety

Introduction

Often, Gas Fired control applications use a Flame Safety System that drives the gas valve to full closed and full open during the start-up sequencefor the burner. HercuLine 2000 Series actuators have been designed to be compatible with the Flame Safety Systems and to perform the required operations.

Configuration

In the Input Set Up Group (Page 29), configure the parameter FSTYPL to Down . In the Digital Input Set Up group (Page 41), configure the parameter DIG INP to Up.

Wiring

Figure 33 shows a Typical Flame Safety Module wiring diagram.




Figure 33 Burner Control/Flame Safety Wiring