

SER8300 User Interface Guide

SER8300 Series Room Controller

Commercial and Hotel/Lodging HVAC Fan Coil Applications




CONTENTS

HMI Display	2
How to Enter Setup Screen	3
Setup Screen Display	3
Clock Settings	5
Schedule Settings	6
Occupancy Settings	7
Wireless Ecosystem	8
Lua Settings	9
ZigBee® Network Settings	11
BACnet® Network Settings	14
BACnet® Instance Number	15
Configuration Parameters	16
Setpoints Settings	28
Display Settings	30
User HMI - Hospitality	31
User HMI - Commercial	31
Other Functions	32
Customizable Color Options	33
Setpoint Adjustment	33
Service Views	37
Test Outputs Screen	39
Language Selection	40


HOME SCREEN DISPLAY

Hospitality User Interface Shown



Note: User HMI is configurable and allows display functions such as Date, Time, Humidity, Outdoor Temperature, Setpoint, and others to be enabled or disabled by setting various parameters.


HOW TO ENTER SET-UP SCREEN



Touch and hold this point for 3 seconds to enter setup mode

Note: If a configuration/installer password is activated to prevent unauthorised access to the configuration menu parameters, a password entry prompt shows to prevent access to device configuration components.

SETUP SCREEN DISPLAY



Note: The "Network" button does not show if BACnet® or ZigBee® Pro card is installed.

- Network Enter BACnet® and ZigBee® network settings
- Configuration Enter parameter configuration menu
- Setpoints - Display Enter setpoint & display settings
- Service View Enter status and service view
- Test Outputs Enter output testing mode
- Language Selection Enable selected language(s)*

Return to home screen


Discover Mode Controller becomes discoverable on wireless ZigBee® Pro network (hidden if ZigBee® Pro settings are not configured)

General Note:

- Adjustable parameter
- Nonadjustable parameter
- Indicates invisible conditional field. Appears based only on model, presence of a ZigBee® wireless adapter module or presence of a Lua script, depending on the field.


*only available in recent versions of firmware

SET-UP SCREEN DISPLAY 2/2




- Enter Schedule menu screen
- Enter Wireless Ecosystem menu screen (ZigBee wireless adapter module required)
- Enter Lua script settings (Lua script required)

SCHEDULE MENU SCREEN



- Enter Clock settings
- Enter Schedule settings
- Enter Occupancy settings



Touch and hold this point for 3 seconds to enter the Schedule Menu screen.

Note: The Schedule menu screen is directly accessible from the main display if the Schedule Menu configuration parameter is enabled. See Configuration Parameters Screen 6/7 on page 26 for more information.

CLOCK SETTINGS

The Clock settings screen allows the device's internal time settings to be changed, including current time, standard day, month, year and weekday options, as well as choice between a 12 hour AM / PM display or a 24 hour display.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Time Format Current time display format Default value: AM-PM	Choice between 12 hour AM - PM time format or 24 hour time format. AM-PM 24 Hours Note: Changing the value of this parameter automatically changes the format of the displayed value of the Time parameter directly below.
Time Current time display setting Default value: Begins at 12:00 AM at initial power up.	Standard time display, 12 hour AM-PM or 24 hour; format is determined by the Time Format parameter value.
Year Default value: 2000	Current year
Month Default value: Jan.	Current month
Day Default value: 01	Current day
Weekday Default value: Sunday	Current day of the week

SCHEDULE SETTINGS

There are 7 different schedule setting screens, one for each day of the week, titled accordingly. Each day can have different scheduled events where the room controller is set to Occupied status or back to Unoccupied status and use the appropriate setpoints, back and forth up to 3 times per day.




Screen title is identified by day of the week (Sunday through Saturday)

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Occupied Default value: None	Defines a time when the room controller is automatically set to use the Occupied setpoint. Note: There are 3 separate Occupied parameter entries
Unoccupied Default value: None	Defines a time when the room controller is automatically set to use the Unoccupied setpoint. Note: There are 3 separate Unoccupied parameter entries

OCCUPANCY SETTINGS

The occupancy settings screen allows you to determine how the Room Controller will determine whether it is functioning in Occupied or Unoccupied mode.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
<p>Occupancy cmd Default value: Local occ</p>	<p>Occupancy Command</p> <p>Loc occ: occupancy is determined by local sequences (either PIR or schedule, as configured under Occ. source).</p> <p>Occupied: force occupied mode.</p> <p>Unoccup: force unoccupied mode.</p>

WIRELESS ECOSYSTEM

When ZigBee wireless sensors are set up to communicate with a Room Controller, the functioning of each such sensor is described in a separate Zone screen, up to a maximum of 10 Zones. Select the appropriate type of sensor based on the required functioning using the up and down arrow keys.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Set function to Describe function of specified wireless sensor Default value: None	None: No sensor function configured for this zone Door: Sensor is a door contact switch Window: Sensor is a window contact switch Motion: Sensor is a motion sensor Status: Updates the BACnet status of the sensor, but no action is taken by the internal logic of the controller. Remove: Selecting this function clears the zone of the settings for the attached sensor. However, the sensor will automatically try to reconnect with the room controller unless it is manually reset as well.
Status Current status of information received from the sensor Read only	Close: Sensor in closed state (door/window only) Open: Sensor in opened state (door/window only) No motion: Sensor detects no motion (motion sensor only) Motion: Sensor detects motion (motion sensor only) None: No status information received from sensor.
Battery Current status of sensor battery, if any. Read only	Low: Battery power level is low, replacement or recharge will be needed soon Normal: Battery power level is in the normal range, replacement or recharge is not currently needed. None: Sensor does not use a battery
Paired Sensor pairing state Read only	No: Sensor is not paired with the room controller Yes: Sensor is paired with the room controller Invalid: Incorrect type of sensor (win/door or motion)

LUA SETTINGS

The LUA settings screens show information about any custom LUA script uploaded to the controller. LUA scripts are not programmable on the controllers, and so must be uploaded to the controllers.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Program cmd Default value: Run	Run: The LUA script is activated and will run continuously until deactivated. Stop: The LUA script is deactivated
Program status Read only	Running: The LUA script is current active Halted: The LUA script has been stopped and is not active. Idle: The LUA script is running but is not currently taking any actions Waiting: The LUA script is running and waiting for a response.
Program error Read only	No error: No errors in the LUA script are detected. Syntax: A syntax error in the LUA script is detected Runtime: A runtime error has occurred while running the LUA script. Memory: The device has run out of memory for the script

LUA GENERIC PARAMETERS

The LUA settings include six generic parameters that do not have predefined values. These can be used to represent LUA script variables. They are user configurable in their default state, but when they are assigned a value by a LUA script they become read only, and the display colour of the parameter changes to red. These parameters are also modifiable through BACnet as Analog Values (AVs). These parameters can be configured to receive information from ZigBee sensors.



A parameter defined by a LUA script displays in red text.

The default value is normally 0, but it can be user-configured to use a different default value.


PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Parameter A Default value: 0 Default value can be changed by user	AV25 The value(s) of this parameter depends on what is assigned to it using the LUA script function
Parameter B Default value: 0 Default value can be changed by user	AV26 The value(s) of this parameter depends on what is assigned to it using the LUA script function
Parameter C Default value: 0 Default value can be changed by user	AV27 The value(s) of this parameter depends on what is assigned to it using the LUA script function
Parameter D Default value: 0 Default value can be changed by user	AV28 The value(s) of this parameter depends on what is assigned to it using the LUA script function
Parameter E Default value: 0 Default value can be changed by user	AV29 The value(s) of this parameter depends on what is assigned to it using the LUA script function
Parameter F Default value: 0 Default value can be changed by user	AV30 The value(s) of this parameter depends on what is assigned to it using the LUA script function

© 2015 Schneider Electric. All rights reserved.

ZIGBEE PRO NETWORK SETTINGS

ZigBee Pro set-up screen shows when ZigBee card is detected in model. Select desired parameter and use up or down arrow to set parameter to desired value.




PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
<p>COM address Terminal Equipment Controller networking address Default value = 254 Range is: 0 to 254</p>	<p>For wireless models, the use of the COM address is not mandatory. The COM address is an optional way to identify a device on the network and is recommended if used with an MPM.</p> <p>It is Mandatory for BACnet</p>
<p>ZigBee® Pan ID Personal Area Network Identification Default value = 0 Range is: 1 to 1000</p>	<p>This parameter (PAN ID) links specific Terminal Equipment Controllers to specific ZigBee® coordinators. For every Terminal Equipment Controller reporting to a coordinator, make sure you set the SAME channel value both on the coordinator and the Terminal Equipment Controller(s).</p> <p>The default value of 0 is NOT a valid PAN ID. The valid range of available PAN ID is from 1 to 1000.</p> <p>Range 1 to 500 for centralized networked applications using a ZigBee® Coordinator.</p> <p>Range 501 to 1000 is for stand-alone applications where each controller is its own coordinator for stand alone installation of wireless door and window switches.</p>

PARAMETER DETAILS


Configuration parameters default value	Significance and adjustments
ZigBee® channel Channel selection Default value = 10 Range is: 10 to 25	This parameter (Channel) links specific Terminal Equipment Controllers to specific ZigBee® coordinators. For every Terminal Equipment Controller reporting to a coordinator, make sure you set the SAME channel value both on the coordinator and the Terminal Equipment Controller(s). Using channels 15 and 25 is recommended. The default value of 10 is <i>NOT</i> a valid channel. The valid range of available channel is from 11 to 25.
ZigBee® status (read only)	(Not Det): ZigBee® module not detected (Pwr On): ZigBee® module detected but not configured (No NWK): ZigBee® configured but no network joined (Joined): ZigBee® network joined (Online): Communicating



Note: The display will return to the home screen when no activity is detected for 1 minute.

PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
Permit join Default value = On	Changing this value to "Off" locks out any new ZigBee® devices from joining the network through this controller.




Note: The display will return to the home screen when no activity is detected for 1 minute.

PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
IEEE address Default value = 0x0000	The extended IEEE ZigBee® node address is used to identify the device on the network.

BACNET NETWORK SETTINGS

BACnet network set-up screen shows when BACnet is detected in model. Select desired parameter and use up or down arrow to set parameter to desired value.



PARAMETER DETAILS


Configuration Parameters Default Value	Significance and Adjustments
Comm address Terminal Equipment Controller networking address Default value: 254 Range: 0 to 254	Communication Address For BACnet® MS-TP models, the valid range is from 1 to 127. Default value of 254 disables BACnet® communication for the Terminal Equipment Controller.
Network units Default value: Imperial	Measurement Units Imperial: network units shown as Imperial units. SI: network units shown as International Metric units.
Network lang Default value: English	Language Settings Choice of network language/object names transmitted over network. All available choices: (English, French, and Spanish).
Baud rate Default value: Auto	Baud Rate Auto: automatically detects BACnet® MS/TP baud rate. Other choices: (115200, 76800, 57600, 38400, 19200, and 9600). Leave the value at auto unless instructed otherwise.

BACNET INSTANCE NUMBER


The default BACnet® instance number is generated by the model number and COM address of the controller. For example, the instance number of a SE8300U5B00 with a COM address of 57 is generated as “83057”.

The default instance number appears first. To change the instance number, use number pad and press **Accept and save**.

Press Reset to automatic instance addressing to reset to automatic instance addressing.



CONFIGURATION PARAMETERS 1/7




PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
<p>BI1 config Binary input no.1 configuration Default value = None</p>	<p>Binary Input No. 1 None: no function associated with input Rem NSB: remote NSB timer clock input. The scheduling gets set as per the binary input and provides low cost setback operation via a dry contact. Motion No and Motion NC: advanced PIR occupancy functions using a Normally Open (NO) or Normally Closed (NC) remote PIR motion sensor. Window EMS: forces system to disable any current heating or cooling action by Terminal Equipment Controller.</p>
<p>BI 2 configuration Binary input no.2 configuration Default value = None</p>	<p>Binary Input No. 2 None: no function associated with input. Door Dry: door contact and motion detector. Override: temporary occupancy remote override contact.</p>

PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
<p>RUI1 config Remote Universal input no.1 configuration Default value = None</p>	<p>Remote Universal Input No. 1</p> <p>None: No function will be associated with the input. Input can be used for remote network monitoring.</p> <p>Filter: "Filter alarm" will be displayed on the Terminal Equipment Controller LCD screen when the input is energized.</p> <p>Service: "Service alarm" will be displayed on the Terminal Equipment Controller LCD screen when the input is energized.</p> <p>COC/NH: change over dry contact; normally heat. Used for hot/cold water or air change over switching in 2 pipe systems.</p> <p>COC/NC: change over dry contact; normally cool. Used for hot/cold water or air change over switching in 2 pipe systems.</p> <p>COS: change over sensor. Used for hot/cold water or air changeover switching in 2 pipe systems.</p>
<p>RBI 2 config Remote Binary input no.2 configuration Default value = None</p>	<p>None: No function will be associated with the input. Input can be used for remote network monitoring.</p> <p>Filter: "Filter alarm" will be displayed on the Terminal Equipment Controller LCD screen when the input is energized.</p> <p>Service: "Service alarm" will be displayed on the Terminal Equipment Controller LCD screen when the input is energized.</p>
<p>Occupancy src Default value: Motion</p>	<p>Occupancy Source</p> <p>Motion: occupancy status is received from a motion sensor.</p> <p>Schedule: occupancy status is determined by the schedule.</p>
<p>Smart recovery Smart recovery enabled Default value: Off Smart recovery is automatically disabled if UI 16 and / or UI 17 are configured remote NSB</p>	<p>Off = no smart recovery The occupied schedule time is the time at which the system will restart.</p> <p>On = smart recovery active. The occupied schedule time is the time at which the desired occupied temperature will be attained. The controller will automatically optimize the equipment start time.</p> <p>In any case, the latest a system will restart is 10 minutes prior to the occupied period time.</p>

CONFIGURATION PARAMETERS 2/7




PARAMETER DETAILS SCREEN 2/7

Configuration parameters default value	Significance and adjustments
<p>Auto mode Default value: On</p>	<p>Auto Mode Enables auto function for the mode button For sequences 2, 4, and 5 only On: auto active (Off-Cool-Heat-Auto) Off: auto not active (Off-Cool-Heat)</p>
<p>Fan menu Default value = Local</p>	<p>Fan Speeds User fan menu presented is dependent on selected fan sequence of operation for the fan coil. L-M-H: 3 Speed configuration using 3 fan relays. L-H: 2 Speed configuration using 2 fan relays. L-M-H-A: 3 Speed configuration with Auto fan speed mode using 3 fan relays. Auto Mode operation is dependent on Auto Fan parameter. L-H-A: 2 Speed configuration with Auto fan speed mode using 2 fan relays. Auto Mode operation is dependent on Auto Fan parameter. On-Auto: single Speed configuration. Auto is for Fan on demand/On is On all the time.</p>
<p>Auto fan func. Auto Fan Function Default value: AS</p>	<p>Automatic Fan Function Auto Speed Fan Mode operation for Fan Menu (L-M-H-A) or (L-H-A). AS: auto speed during occupied periods. Fan is always on during occupied periods. AS/AD: auto Speed/Auto Demand during occupied periods.</p>

PARAMETER DETAILS SCREEN 2/7

Configuration parameters default value	Significance and adjustments
<p>Fan cont. heat Default is: On</p>	<p>Fan control in heating mode</p> <p>On: the controller in all cases will always control the fan (terminals Low-Med—Hi Fan Speed). Valid in any fan sequences and all the available fan modes.</p> <p>Off-Auto: the controller in all cases will disable the fan (any terminals Low-Med—Hi Fan Speed). ONLY when the local fan mode is set to Auto. Valid in all fan sequences with auto mode.</p> <p>Off-All: the controller in all cases will disable the fan (any terminals Low-Med—Hi Fan Speed). When the local fan mode is set to ANY mode. Valid in all fan sequences and all local fan modes.</p>
<p>Standby mode Default value: Abs</p>	<p>Standby Mode</p> <p>Choose which standby setpoints are used for control.</p> <p>Abs: absolute; Standby entered values are used for standby mode.</p> <p>Offset: offset; Occupied setpoints +/- Standby diff. used for standby mode.</p>
<p>Standby diff. Default value: 2 °C (3 °F)</p>	<p>Standby Difference</p> <p>When Standby mode is Relative, standby setpoints are calculated as:</p> <p>Standby cool = Cool setpoint + Standby diff.</p> <p>Standby heat"= Heat setpoint - Standby diff.</p> <p>Adjustable from 0.5 a 2.5 °C (1 - 5 °F)</p>

CONFIGURATION PARAMETER 3/7



★ These parameters are only displayed on models with built in humidity sensor


PARAMETER DETAILS SCREEN 3/7

Configuration parameters default value	Significance and adjustments
<p>Standby time Default 0.5 hours</p>	<p>Standby Time Time delay between the moment where the PIR cover detects last movement in the area, and the time which the Terminal Equipment Controller stand-by setpoints become active. Range: 0.5 to 24.0 hours in 0.5 hours increments.</p>
<p>Unocc. time Default 0.0 hours</p>	<p>Unoccupied Time Time delay between the moment where the Terminal Equipment Controller toggles to stand-by mode, and the time which the Terminal Equipment Controller unoccupied mode and setpoints become active. Factory value 0.0 hours: Setting this parameter to its default value of 0.0 hours disables the unoccupied timer. This prevents the Terminal Equipment Controller to drift from stand-by mode to unoccupied mode when PIR functions are used. Range: 0.0 to 24.0 hours in 0.5 hours increments.</p>
<p>Temp. occ. time Default value = 2 hours</p>	<p>Temporary Occupancy Time Temporary occupancy time with occupied mode setpoints when override function is enabled. When Terminal Equipment Controller is in unoccupied mode, function is enabled with either the menu or BI2 configured as remote override input. Range: 0 - 24 hours.</p>

PARAMETER DETAILS SCREEN 3/7

Configuration parameters default value	Significance and adjustments
<p>Deh. hysteresis Default value = 5 % RH</p>	<p>Humidity Control Hysteresis Used only if dehumidification sequence is enabled: Range: 2 to 20% RH Models with humidity sensor only.</p>
<p>Deh. max. cool. Default value = 100 %</p>	<p>Maximum Dehumidification Cooling Maximum cooling valve position when dehumidification is enabled. This can be used to balance smaller reheat loads installed in regards to the capacity of the cooling coil. Range: 20 to 100 % Models with humidity sensor only.</p>
<p>Deh. lockout Default value: Enabled</p>	<p>Dehumidification Lockout Typically toggled through the network. This variable enables or disables dehumidification based on central network requirements from the BAS front end. Enabled = Dehumidification Authorized Disabled = Dehumidification Not Authorized Models with humidity sensor only.</p>

CONFIGURATION PARAMETERS 4/7



PARAMETER DETAILS SCREEN 4/7


Configuration parameters default value	Significance and adjustments
<p>Cool CPH Default value = 4 C.P.H.</p>	<p>Cooling output cycles per hour Will set the maximum number cycles per hour under normal control operation. It represents the maximum number of cycles that the equipment will turn ON and OFF in one hour. Note that a higher C.P.H will represent a higher accuracy of control at the expense of wearing mechanical components faster. Range is: 3, 4, 5, 6,7 & 8 C.P.H.</p>
<p>Heat CPH Default value = 4 C.P.H.</p>	<p>Heating output cycles per hour Sets the maximum number cycles per hour under normal control operation. It represents the maximum number of cycles that the equipment will turn ON and OFF in one hour. Note that a higher C.P.H will represent a higher accuracy of control at the expense of wearing mechanical components faster. Range is: 3, 4, 5, 6,7 & 8 C.P.H.</p>
<p>Cooling valve Default value = NC</p>	<p>Sets the type of valve used for cooling NC = Valve is normally closed when no power is present. NO = Valve is normally opened when no power is present.</p>
<p>Heating valve Default value = NC</p>	<p>Sets the type of valve used for heating. NC = Valve is normally closed when no power is present. NO = Valve is normally opened when no power is present.</p>

© 2015 Schneider Electric. All rights reserved.

PARAMETER DETAILS SCREEN 4/7

Configuration parameters default value	Significance and adjustments
<p>Setpoint func. Local setpoint settings Default value: Dual SP</p>	<p>Setpoint function Sets the local setpoint interface for the user Dual SP (Dual Occupied Setpoints Adjustment) Attach SP (Single Occupied Setpoint Adjustment)</p>
<p>Mode button Default value: Normal</p>	<p>Mode button Determines whether all HVAC functions are available to user control. Normal: All HVAC functions available based on current application can be accessed through cycling Mode button functions Off-Auto: Only Auto and Off settings are available by cycling the Mode button.</p>

CONFIGURATION PARAMETERS 5/7



PARAMETER DETAILS SCREEN 5/7

Configuration parameters default value	Significance and adjustments																														
<p>Prop. band Default value= 3</p>	<p>Proportional Band Setting</p> <p>Adjusts proportional band used by the Terminal Equipment Controller PI control loop.</p> <p>Note: default value of 3.0 gives satisfactory operation in most normal installation cases. The use of a superior proportional band different than the factory one is normally warranted in applications where Terminal Equipment Controller location is problematic and leads to unwanted cycling of the unit. A typical example is a wall mounted unit where Terminal Equipment Controller is installed between return and supply air feeds and is directly influenced by the supply air stream of unit.</p> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <thead> <tr style="background-color: #008000; color: white;"> <th style="width: 25%;">Value</th> <th colspan="2" style="width: 75%;">Effective Proportional Band</th> </tr> <tr> <td></td> <th style="width: 25%;">Fahrenheit</th> <th style="width: 25%;">Celsius</th> </tr> </thead> <tbody> <tr><td>3</td><td>3</td><td>1.2</td></tr> <tr><td>4</td><td>4</td><td>1.7</td></tr> <tr><td>5</td><td>5</td><td>2.2</td></tr> <tr><td>6</td><td>6</td><td>2.8</td></tr> <tr><td>7</td><td>7</td><td>3.3</td></tr> <tr><td>8</td><td>8</td><td>3.9</td></tr> <tr><td>9</td><td>9</td><td>5.0</td></tr> <tr><td>10</td><td>10</td><td>5.6</td></tr> </tbody> </table>	Value	Effective Proportional Band			Fahrenheit	Celsius	3	3	1.2	4	4	1.7	5	5	2.2	6	6	2.8	7	7	3.3	8	8	3.9	9	9	5.0	10	10	5.6
Value	Effective Proportional Band																														
	Fahrenheit	Celsius																													
3	3	1.2																													
4	4	1.7																													
5	5	2.2																													
6	6	2.8																													
7	7	3.3																													
8	8	3.9																													
9	9	5.0																													
10	10	5.6																													

© 2015 Schneider Electric. All rights reserved.

PARAMETER DETAILS SCREEN 5/7

Configuration parameters default value	Significance and adjustments	
Pulsed heating Default value = Off	VDC output configuration. SC3000 series model dependent. Off = Regular On-Off control for SC350xE models only. Can be used with 2 & 4 pipes applications. On = VDC SSR electric heat 10 second pulsed time base modulation for SC340xE models only. Can only be used with 2 pipes system only. Occ Out = VDC Occupancy output follows local device occupancy for SC3514E model only. <ul style="list-style-type: none"> • Occupied & Temporary Occupied = Contact closed • Stand-By & Unoccupied = Contact opened 	
No. of pipes Default is: 2 Pipes	Number of pipes Defines the type of system installed.	
Operation seq. Default is: Heating only	Operation sequence Selects the initial sequence of operation required by the installation type and the application.	
	2 Pipes	4 Pipes
Cool only	Cooling only	Cooling only
Heat only	Heating only	Heating only
Cool / Heat	Cooling with electric reheat	Heating / Cooling
Heat-Rht	Heating with electric reheat	---
Reheat	Electric reheat only	---
	For 2 Pipe output applications, the system access is limited if RUI 1 is configured for local changeover COS, COC/NC or COC/NC. The current water temperature detected by the RUI 1 then limits the system mode available for the local configuration or network write. For sequence "electric reheat", set PulsedHt to "On" to enable pulsed electric reheat applications with SC3400E & SC3404E.	
Purge sample Default is: 2 hrs	Time interval between valve samples. Will open valve for a short period adjusted by "Purge open" parameter in order to sample pipe temperature to decide between heating or cooling mode. Adjustable from 0 to 4 hrs. (0 = disable this function).	
Purge open Default is: 2 min	Time the valve will open to sample pipe temperature (to decide between heating or cooling mode). Adjustable from 1 to 3 min.	

CONFIGURATION PARAMETERS 6/7

6/7 Configuration

Main password	0
User password	0
Schedule menu	Enable
Calib. temp.	0.0 °C
Calib. humid.	0.0 %RH

Navigation icons: Back, Home, Up, Down




This parameter is only displayed on models with built in humidity sensor

PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
Main password Default value = 0	Installer password This parameter sets a protective access password to prevent unauthorized access to the configuration menu parameters. A default value of "0" will not prompt a password or lock the access to the configuration menu. Range is: 0 to 9999.
User password Default value = 0	User password This parameter sets a protective access password to prevent user unauthorized access to main screen adjustments. A default value of "0" will not prompt for a password. Range is: 0 to 9999.
Schedule menu Default value: Enabled Toggles activation of schedule menu direct access	Enabled The Schedule Menu is directly accessible from the main screen via a touch in the upper corner (see page 4). Disabled The Schedule Menu can only be accessed through the Setup Menu screens
Calib. temp. Default value = 0.0 °C or °F	Room temperature sensor calibration Offset that can be added/subtracted to actual displayed room temperature. Range is: ± 2.5 °C, 0.1 °C increments (± 5.0 °F, 0.1 °F increments).
Calib. humid. Default value = 0 %RH	Humidity sensor calibration Offset that can be added/subtracted to actual displayed humidity. Range is : ± 15.0 %RH. Models with humidity sensor only.

CONFIGURATION PARAMETERS 7/7



PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
Erase all ? Are you sure ? Default values = No	Answering "Yes" to these two questions and pressing the "Accept" button, will erase all values to factory's default values except the following network-related values: COM address, ZigBee® Pan ID, ZigBee® channel, Network units, Network lang., Baud rate, BACnet® instance, Device name.


SETPOINT SETTINGS 1/2



PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
Unocc. cool Default value = 26.5 °C (80 °F)	Unoccupied cooling setpoint Range is: 12.0 to 37.5 °C (54 to 100 °F)
Standby cool Default value = 25.5 °C (78 °F)	Standby cooling setpoint The value of this parameter should be set between the occupied and unoccupied cooling setpoints. Make sure that the difference between the stand-by and occupied value can be recovered in a timely fashion when movement is detected in the zone. Stand-by cooling setpoint range is: 12.0 to 37.5 °C (54 to 100 °F).
Occ. cool Default value = 24.0 °C (74 °F)	Occupied cooling setpoint Range is: 12.0 to 37.5 °C (54 to 100 °F).
Occ. heat Default value = 22.0 °C (72 °F)	Occupied heating setpoint Range is: 12.0 to 37.5 °C (54 to 100 °F).
Standby heat Default value = 20.5 °C (69 °F)	Stand-by heating setpoint The value of this parameter should be set between the occupied and unoccupied heating setpoints. Make sure that the difference between the stand-by and occupied value can be recovered in a timely fashion when movement is detected in the zone. Stand-by heating setpoint range is: 4.5 to 32.0 °C (40 - 90 °F).
Unocc. heat Default value = 16.5 °C (62 °F)	Unoccupied heating setpoint Range is: 4.5 to 32.0 °C (40 to 90 °F).

SETPOINT SETTINGS




* This parameter is only displayed on models with built in humidity sensor

PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
Default heat Default value = 22.0 °C (73 °F)	Default Heat Used for hospitality applications in stand-alone mode only. When devices are in deep unoccupied mode, any movement detected by PIR resets actual occupied set points to fresh room default setting. Default setpoint is used to write to Heating setpoint when the Room Controller goes to Unoccupied mode. Cooling setpoint is set according to Min. deadband; 18.5 to 26.5 °C (65 to 80 °F). This parameter is only used when Stand-by mode = Offset.
Min. deadband Default value = 1.5 °C (3.0 °F)	Minimum deadband value between the heating and cooling setpoints. Applied only when any of the setpoints are modified. Range is: 1.0 to 2.5 °C, 0.5 °C increments (2, 3, 4 or 5 °F, 1.0 °F increments).
Max heating Default value = 32.0 °C (90.0 °F)	Maximum occupied & unoccupied heating setpoint adjustment. Range: 4.5 to 32.0 °C (40 to 90 °F).
Min. cooling Default value = 12.0 °C (54.0 °F)	Minimum occupied & unoccupied cooling setpoint adjustment. Range: 12.0 to 37.5 °C (54 to 100 °F).
Dehum. SP Default value = 50 % RH	Dehumidification setpoint Used only if dehumidification sequence is enabled: Range is: 30-95% RH. Models with humidity sensor only

DISPLAY SETTINGS



PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
User HMI Default value = 0	Select user HMI type. Range: 0 to 11.




User HMI - hospitality

0 (Hospitality)

1 (Hospitality)

2 (Hospitality)


3 (Hospitality)




These parameters are model dependent and may not appear on certain models.

User HMI - hospitality


4 (Hospitality)



5 (Hospitality)




6 (Hospitality)




User HMI - commercial


7 (Commercial)




8 (Commercial)



9 (Commercial)




10 (Commercial)



11 (Commercial)



Note: The day/night setback button  appears only in unoccupied mode from 7 to 11 in HMI Commercial. If BI2 input is configured as "override", the day/night setback button does not show.

These parameters are model dependent and may not appear on certain models.

Other functions

09.26.2012 12:54 PM
Room 1705
Standby

Indoor °C
23.5°

Humidity 45% | Outdoor 18°C

09.26.2012 12:54 PM
Room 1705
Standby

Indoor °C
23.5°

Humidity 45%

09.26.2012 12:54 PM
Room 1705
Standby

Indoor °C
23.5°

Outdoor 18°C

RH Display = Configuration + model dependent
Outdoor Temp = When set by network

Heating only configuration

09.26.2012 12:54 PM
Room 1705
Standby

Setpoint °C
23.5°


Humidity 45% | Outdoor 18°C

Time and Date shows only if it has been properly set

If main display parameter is set to "setpoint", the **setpoint value** is as shown

On/Off shows when the sequence of operation is set to heating or cooling only

Setpoint adjustment




Cooling mode or cooling only sequence of operation

In Cooling mode, the setpoint displayed in the bar is the current occupied cooling setpoint.

During occupied setpoint adjustment, the large digits are temporarily used to display the occupied cooling setpoint while it is adjusted.

Normal temperature display resumes after the setpoint is adjusted and the actual occupied cooling setpoint is displayed in the setpoint bar.




Heating mode or heating only sequence of operation

In Heating mode, the setpoint displayed in the bar is the current occupied heating setpoint.

During occupied setpoint adjustment, the large digits are temporarily used to display the occupied heating setpoint.

Normal temperature display resumes after the setpoint is adjusted and the actual occupied heating setpoint is displayed in the setpoint bar.



Automatic Heating / Cooling mode

In automatic mode, the setpoint displayed at the top of the set point bar located directly under the blue line represents the actual occupied cooling setpoint.

During occupied setpoints adjustment, the large digits are temporarily used to display the occupied "Cooling Setpoint" or occupied "Heating Setpoint". The actual setpoint is dependent on the last effective demand (heating or cooling).

Normal temperature display resumes after the setpoints are adjusted and the actual occupied heating and cooling setpoints are displayed in the setpoint bar.

PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
Color Default value = White	Select user HMI colour. Other choices: Green, Blue, Dark Grey, and Grey.
Main display Default value = Temp.	Select default value displayed on main display: Temperature or setpoint. Choices: Temperature or setpoint.
Disp. cust. img. Default value = No	Selecting "Yes" shows a custom image after 2 minutes of touch screen inactivity.
Contrast Default value: 0	Controls the screen contrast and brightness. 0 is least bright, most contrast; 5 is most bright, least contrast. Range: 0 to 5

Customisable colour options



White



Green



Blue




Dark Grey



Grey

DISPLAY SETTINGS



* This parameter is only displayed on models with built in humidity sensor

PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
Language Default value: English Only EN, FR and SP available for BACnet models.	Language Select language for main display. Choices: English, French, Spanish, Chinese, Russian, Arabic, Bulgarian, Czech, Danish, Dutch, Finnish, German, Hungarian, Indonesian, Italian, Norwegian, Polish, Portuguese, Slovak, Swedish, Turkish
Units Default value = °C	Temperature Units Sets default local scale value when Terminal Equipment Controller powers up. °C for Celsius. °F for Fahrenheit.
Low backlight Default value is 60%	Backlight Display Set display backlight intensity after 2 minutes of keyboard inactivity. Adjustable: 0 to 100%.

PARAMETER DETAILS

Configuration parameters default value	Significance and adjustments
<p>Night backlight Default value = 5%</p>	<p>Night Backlight Display</p> <p>Set display backlight intensity after 2 minutes of keyboard inactivity.</p> <p>Adjustable: 0 to 100%.</p> <p>Parameter only available for models with motion/light detectors. The screen backlight progressively decreases down to this setting when room is dark. This feature is used mostly in hospitality applications when a darker non obtrusive lighting level is desired when room is dark.</p>
<p>RH display Default value = Disabled</p>	<p>Relative Humidity Display</p> <p>Enables display of humidity below room temperature on the display</p> <p>(On): Display %RH. (Off): Do not display %RH.</p> <p>Models with humidity sensor only</p>

SERVICE VIEWS

The service view screens show the current status of certain points locally at the controller. These points can also be viewed through the network.

1/5 Service view

Firmware revision of the controller	Firmware rev.	1.0	
	Room temp.	xx.x °C	Room temperature
Changeover temperature	Changeover	xx.x °C	
	Supply temp.	xx.x °C	Supply temperature
Outdoor temperature	Outdoor temp.	xx.x °C	
	Room humidity	xx.x %RH	Room Humidity


Note: A green asterisk () is placed next to the 'Room humidity' parameter label.*

2/5 Service view


Effective occupancy	Effective occ.	Occupied	
	PI cool demand	0 %	PI cooling demand
PI heating demand	PI heat demand	0 %	
	Cool dem. limit	0 %	Cooling demand limit
Heating demand limit	Heat dem. limit	0 %	

***** This parameter is only displayed on models with built in humidity sensor

SERVICE VIEWS



* This parameter is only displayed on models with a installed ZigBee communication module



* This parameter is only displayed on models with built in humidity sensor


SERVICE VIEWS

Note: This represents BACnet® device name automatically assigned using the current BACnet® MAC address.

The network can update and change the device BACnet® name. If changed, the new updated BACnet® device name shows



TEST OUTPUTS SCREEN



Note 1: Cooling output can also be used for heating on two pipes systems.

Note 2: The test output screen allows manual override of specified outputs. When any BACnet® network priority array includes a value, the status background shows in red. After any output state is overridden, the command is cancelled after 1 min of screen inactivity (auto exit to main screen) or when page is exited. Refer to the BACnet® integration guide for more details.

LANGUAGE SELECTION



Only English, French, Spanish, Chinese and Russian are enabled by default, which means that they will be accessible to users cycling through languages on the display settings menu screen. To change the language selection settings, touch a language on the screen and then use the arrow buttons to disable or enable it. The English language is always enabled.